

PARTS REQUIRED FOR INSTALLATION AND OPERATION - NOT SUPPLIED

1. Residual current device (RCD) with a rated residual operating current not exceeding 30mA.

OPTIONAL PARTS - NOT SUPPLIED

1. Micro SD Memory Card
2. Ethernet cable (only required for network connection via ethernet, instead of WiFi).

PARTS LIST

- | | |
|--|---|
| 1. Camera head (shown without optional silicone jacket) (9852) | 10. REEF-Cam WiFi hub (9853) |
| 2. Camera lens | 11. WiFi antenna |
| 3. REEF-Cam cable | 12. Power ON indicator |
| 4. Multi-directional ball pivot joint bracket (9858) | 13. Micro SD card slot |
| 5. A. Magnet Mount Bracket (9855)
B. Suction Cup Mount Bracket (9856) | 14. Camera cable USB connection port |
| 6. Locking suction cup securing knob (suction cup mount bracket only) | 15. PSU port |
| 7. Cable retaining slot | 16. Ethernet cable port |
| 8. Cable securing clip (9859) | 17. WiFi hub self-adhesive securing pad |
| 9. REEF-Cam PSU (9854) | 18. Camera lens cleaning cloth |
| | 19. Optional external tank fitting bracket (9857) |
| | 20. Optional silicone camera jackets x 2 (camera is supplied fitted with black jacket) (9860) |

